

INTIEL
THE ELECTRONICS ON YOUR SIDE
FUEL LEVEL RESET MODULE

User's Manual

1. Technical description

Fuel level reset module is designed for installation in Auto gas equipment to reset the measurement of the fuel during certain period of time.


2. Operation

The Module is being connected to the power supply of the fuel level gauge of the liquid fuel, as every 7 minutes connects the fuel level gauge through 100Om resistor to the negative terminal of the battery / ground of the vehicle / for periods of 1 minute. In this case it is recommended the installation of Fuel Level Reset Module in order to prevent detection of errors from the board computer, because when the car engine running with gas, it does not consume a liquid fuel.

3. Technical data

- | | |
|--------------------------------|--------------------|
| 1. Power system voltage | 12V/DC |
| 2. Protection level | IP-65 |
| 3. Time OFF state | 7 to 8 min. |
| 4. Time ON state | 55 to 65sec. |
| 3. Operating temperature range | from -10C to +55 C |
| 4. Humidity of the environment | up to 95% |

4. Connection scheme



5. Warranty

The warranty period is 24 months following the purchase date of the unit or its installation by an authorized Engineering Company, but not exceeding 28 months after the production date. The warranty is extended to the malfunctions that occur during the warranty period and are result of the production reasons or defective used parts.

The warranty does not relate to malfunctions corresponding to not-qualified installation, activities directed to the product body interference, not regular storage or transport.

The repairs during the warranty period can be done after correct filling of the manufacturer warranty card

Warranty Card

Manufacturer: INTIEL	
Product type	Fuel level reset module
Production number	
Production date	
Dealer confirmation	
Purchase date	
Invoice number	
Dealer's name, address and stamp	
Seller's name and signature	